

DIN : 02244708 1 L
DIN : 02244709 4 L , 20 L , 200 L

Manufactured for Bayer Inc. by Virox Technologies Inc., Mississauga, Ontario L5W 5M4

Distributed by Bayotek International Inc. for use in aquaculture.

Peroxigard contains Accelerated Hydrogen Peroxide (AHP), a patented, colorless and volatile free liquid cleaning and disinfecting solution developed by Virox Technologies Inc.

- AHP is a synergistic blend of commonly used safe ingredients that when combined with low levels of hydrogen peroxide dramatically increase its germicidal activity.
- AHP contains only those ingredients listed on the U.S.A. EPA inert listing and the GRAS listing (Generally Regarded as Safe) published by the EPA which contribute to an unsurpassed health, safety and environmental profile.
- The cleaning efficacy exceeds Canadian General Standards Board (CGSB) thresholds reaching 86.5% (CAN/CGSB-2.16 in conjunction with 2.11).

Peroxigard reduces or eliminates pathogenic organisms with broad spectrum sanitizing in just 30 seconds! Virucidal and bactericidal disinfection is accomplished in five minutes. No other cleaning and disinfecting product can achieve your desired results this fast.

INSTRUCTIONS FOR USE:

READY TO USE

General cleaning & sanitizing: Environmental surfaces (walls and countertops), equipment (hatchery tanks, graders, vaccination equipment, vehicles, nets), footbaths.

Apply solution to the surface and allow it to sit for 30 seconds. Wipe dry, no rinsing is required.

Disinfectant: Environmental surfaces (walls and countertops), equipment (hatchery tanks, graders, vaccination equipment, vehicles, nets), footbaths.

Apply solution to the surface and allow it to sit for 5 minutes. Wipe dry, no rinsing is required.

Note: Heavily soiled surfaces require cleaning prior to disinfection.

CONCENTRATE

Dilution Made Easy

Ratio	Per Litre of water	Per 32 oz. of water
1:16	64 ml	2 oz.
1:64	16 ml	½ oz.

Disinfectant Use Instructions

Heavily soiled surfaces require cleaning prior to disinfection.

Disinfection of Non-critical Items, Equipment and Hard Surfaces

Dilute at 1:16. Apply to the surface with cloth or disposable wipe. Ensure the surface remains wet for 5 minutes at 20°C. Wipe dry or rinse.

Footbaths: Change frequently or when heavily soiled.

Nets: Change frequently.

Broad Spectrum Sanitizing of Environmental Surfaces

Dilute at 1:16. Apply to surface, allow to remain wet for 30 seconds. Wipe dry; no rinsing required. Food contact surfaces require rinsing with potable water.

Cleaning Floors

Dilute at 1:64. Mop; no rinse required.

PEROXIGARD EFFECTIVENESS

See data sheet.

PRECAUTION STATEMENTS

- Keep out of reach of children.
- Undiluted product is corrosive; may cause burns.
- Avoid contact with eyes and skin. Wear suitable protective clothing.
- Do not store in food processing areas.
- Avoid storage at elevated temperatures.
- Do not mix with other cleaning or disinfecting products.
- Read MSDS before using product.

FIRST AID

See MSDS Sheet.

DISPOSAL

Dispose of the container in accordance with provincial regulations.

Peroxigard meets stability testing for up to 4 weeks after dilution with tap water.

Germicidal activity of this product was determined in accordance with the Canadian General Standards Board's Standard CAN/CGSB-2.161-97.

Accelerated Hydrogen Peroxide is a registered trademark and patented technology of Virox Technologies Inc. used under license by Bayer Inc. Peroxigard is a trademark of Bayer Inc. Bayer and the Bayer Cross are registered trademarks of Bayer AG, used under license by Bayer Inc.

